



Aqueous Cleaners for Spray or Wipe Procedure - Table 2

Consumable Product	No.	Concentration	Rinse Required?
Gas Path Cleaner Type IIA	C04-140	As Received	Yes
Gas Path Cleaner Type II	C04-140	20%	Yes
Turco 6780	C04-203	Full Strength	No
Ardrox Aviacenz 6077 Window Cleaner Plus	C04-204	Full Strength	No
MagChem Evasol	C04-205	Full Strength	No
Nuvite Nu-Gear-Sc	C04-206	20-25 v/v	Yes
Bio-T-Max	C04-207	Full Strength	Yes

Subtask 70-21-23-110-533

4. Procedure.

- A. Wipe the part with cloth saturated with one of the cleaners identified in Table 1. When using cleaners identified in Table 2, spray or wipe application may be used.

NOTE: Various types of bristle brushes suitable for the part configuration or cleaner pads C10-010 may be used in addition to the wiping cloths to enhance the cleaning process. When using brushes or cleaning pads, a final wipe of the part surface should be performed with a cloth C10-182 saturated with the cleaner being used.

- B. Flush the part completely with clean water when indicated in Table 2.
- C. Dry the part with one of the cloths specified Subtask 70-21-23-110-531, Equipment.
- D. Blow dry with clean, dry air.

70-21-23

Page 3

Apr 01/2003